



# **SURE-FLO®**

## **Wet Well Inlet Adapter**

---



The adapter is designed to attach a Sure-Flo self-cleaning strainer to the inlet pipe of a wet well. It can be used with large diameter PVC pipe, corrugated aluminum pipe, or corrugated steel pipe. The adapter will connect either to the inside of the inlet pipe or to the outside (depending on the inlet pipe's size). The flange portion of the adapter will be large enough to seal off the inlet pipe's end. Installation is quickly made, by adjusting eight bolts with locking nuts, which centers and secures the adapter in place. The Sure-Flo self-cleaner is then inserted and attached to the companion flange socket on the end of the adapter.

---

***Quality and Service Since 1932***

Phone 734-761-5110

**SURE-FLO FITTINGS**  
2077 S.State St. P.O. Box 1363  
Ann Arbor, Mi. USA 48106  
[www.sure-flo.com](http://www.sure-flo.com)

Fax 734-761-8659